



## Relocator for Tour-Pak®

# 8957

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**PROTECT YOURSELF AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS. PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS, AND NOTICES REGARDING THE INSTALLATION, USE, AND CARE OF THIS PRODUCT.**

### WARNING

**THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.**

### CAUTION

**This indication alerts you to the fact that ignoring the contents described herein can result in minor or moderate potential injury.**

### NOTICE

**This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.**

### MAKE SURE THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Right Hand Relocator Block
- 1 Left Hand Relocator Block
- 1 Hardware Kit containing:
  - 4 1/4"-20 X 7/8" Hex Head Cap Screws
  - 8 1/4" Split Lock Washers
  - 8 1/4" Flat Washers
  - 4 Cable Ties
- 1 Installation Instructions

### TOOLS SUGGESTED

Socket set and ratchet, combination wrenches, set of hex wrenches, set of hex sockets, in./lbs. torque wrench

### NOTICE

**This copy of installation instructions contains important information. Ensure that the end user receives this copy and is aware of its importance for future reference.**

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

**STEP 2** Unhook the CB cable (if equipped) located under the clutch-side (left) passenger armrest.

### NOTICE

**Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.**

### CUSTOMER SERVICE

877.370.3604 (toll free)

### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
  - The product must be properly installed, maintained and operated under normal conditions.
  - Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
  - Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.

• Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

For purchasing Küryakyn® products, you can receive a complete catalog free of charge.

Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.



**STEP 3** Open the Tour-Pak. Refer to PIC 1. Remove the two acorn nuts located inside the document pouch in the Tour-Pak. Remove the pouch.

**STEP 4** Remove the trunk liner and set it aside.

**NOTICE** Assistance is highly recommended to secure the Tour-Pak as the mounting screws are being removed.

**STEP 5** Remove the four screws securing the Tour-Pak to the mount. PIC 2 Set the screws aside for now; they will be reused later. Note the location of the ground strap; it will be re-installed later. PIC 2

**STEP 6** Carefully move the Tour-Pak out of the way. Have someone secure the Tour-Pak while the Relocator Blocks are being installed.

**STEP 7** Refer to FIG 1. Determine the Right-and Left-Hand Relocator Blocks. The countersunk holes are offset to ensure that they are installed on the correct side. The beveled edges face the front of the motorcycle.

**STEP 8** Attach the clutch-side (left) Relocator Block to the OEM mount with two of the included 1/4"-20 Screws, Lock Washers and Flat Washers. PIC 3 Insert the screws through the countersunk holes. Leave the first screw loose until the other has been installed, then **Torque the screws to 96 to 100 in./lbs.**

**STEP 9** Repeat STEP 8 for the brake-side (right). PIC 4

**STEP 10** The Relocator allows for three different mounting positions over a range of about three inches. Refer to FIG 1. Determine which of the three mounting positions will work best for you.

**STEP 11** Add an included Lock Washer and Flat Washer to each screw (removed in **STEP 5**) and set them within arms reach of the work area.

**STEP 12** Carefully position the Tour-Pak over the Relocator Blocks. Align the holes in the Tour-Pak with the threaded holes in the Blocks. Attach the Tour-Pak to the Blocks with the screws from **STEP 11**. Leave the screws loose until all have been started in their threaded holes, then **torque the screws to 96 to 100 in./lbs.**

**NOTICE** Ensure that the ground strap (PIC 2) is reattached to the floor of the Tour-Pak during reinstallation.

**STEP 13** Reinstall the Tour-Pak liner.

**STEP 14** Reinstall the document pouch and acorn nuts. Reinstall the CB cable (if removed).

**STEP 15** Ensure the Tour-Pak is secure **before** riding the motorcycle.

**NOTICE** It is the end user's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

*Ride On!*

