



LowandMean.com
928.255.0230

KAWASAKI MEAN STREAK FRONT FENDERS

Part # LM-01-200 : LM-01-201 : LM-01-202

INSTRUCTIONS

Front fender s includes:	WARNING: Do not install with the motor warm. This is an install at your own risk. If you are not capable to install successfully then we highly suggest you take this item to a professional shop. Always check the fit before sending this product off to paint.
4 SS 6mm bolts	
4 SS 6mm washers	
4 Rubber washers	
4 Aluminum collars	

Suggestions for install:

- 1) First, remove the front fender you have on the bike at the moment.
- 2) Next, install the 4 SS bolts (supplied with 4 SS washers) from the inside of the Low and Mean fender.
- 3) place fender onto tire in front of the forks.
- 4) Slide on the rubber washers and then aluminum collars onto each bolt.
- 5) Set the fender into place, lining all the bolts to the fender mounting holes. Try to give each bolt a couple of turns.
- 6) If everything looks in line, then proceed to tightening down. Try to tighten each bolt evenly. Do not just tighten one down then go to the next, otherwise the fiberglass could flex too much.
- 7) Check fit and firmness after your first ride of showing off your *Nice bike*™.



Please contact our Tech support if you have any issues or questions on install
Techsupport@LowandMean.com or 928.255.0230