



KAWASAKI MEAN STREAK SHORTY FRONT FENDER

LowandMean.com

Part # LM-01-202

928.680.6660

INSTRUCTIONS

| | |
|-------------------------|--|
| Front fenders includes: | WARNING: Do not install with the engine warm. This is an install at your own risk. If you feel you are not capable of installing successfully then we highly suggest you take this item to a professional shop. Always check the fit before sending this product off to paint. |
| 4 SS 6mm bolts | |
| 4 SS 6mm washers | |
| 4 Rubber washers | |
| 4 Aluminum collars | |

Suggestions for install:

- 1) Remove the current front fender.
- 2) Insert the 4 Stainless Steel bolts (supplied with 4 SS washers) from the inside of the Low and Mean fender.
- 3) Place the shorty fender onto tire in front of the forks.
- 4) Slide the rubber washers onto each bolt. Slide the aluminum collars onto each bolt behind the rubber washers.
- 5) Set the shorty fender into place, aligning all the bolts with the fender mounting holes. Give each bolt a couple of turns.
- 6) If everything looks in line, then proceed to tightening down. Try to tighten each bolt evenly. Do not just tighten one down then go to the next, otherwise the fiberglass could flex too much and possibly crack.
- 7) Check fit and firmness after your first ride of showing off your **Nice bike™**.

Please contact our Tech support if you have any issues or questions on install



Techsupport@LowandMean.com or 928.255.0230

© 2006-2014 Low and Mean L.L.C.™, All rights reserved.