



LowandMean.com

928.680.6660

HONDA FURY REAPER FRONT FENDER

Part # LM- 02F-200

INSTRUCTIONS

LM- 02F-200 includes:		WARNING: We highly recommend installing this product before painting. Please Do not install this product with the motor warm. This is an install at your own risk. If you are not capable to install successfully then we highly suggest you take this item to a professional shop.
4	Bolts	
4	SS washers	
4	Rubber washers	

Suggestions for install:

- 1) Make sure the bike is stable before removing the stock front fender.
 - 2) The stock front fender is held on by 4 bolts. We suggest a 10mm open end wrench.
 - 3) Once the bolts are loose, remove the fender from the bike.
 - 4) Place the Reaper front fender on the tire.
 - 5) Start on the exhaust side of the bike. Put the SS washers on the bolts, and insert the bolts from the inside. Slide on the rubber washers so they sit on the outside of the fender. Use some Loctite on the bolts.
 - 6) Carefully position the fender in place so you can thread in the bolts.
 - 7) At this time you can get rid of the brake line bracket or install it. If you do install this bracket you will not use the rubber washers on that side of the fender. Install the bolts and washer with Loctite to secure the fender on the brake bracket side.
 - 8) Make sure to evenly tighten down the bolts, so the fender sits even from left to right. Make sure the side of fender follows the rim for the correct position.
- Always check your work before you ride safe!

Figure 1.1



Figure 1.2



Figure 1.3



Please send us a picture of your new Front Fender on your *Nice bike*™.

Please contact our Tech support if you have any issues or questions about install

Techsupport@LowandMean.com or 928.680.6660

© 2006-2014 Low and Mean L.L.C.™, All rights reserved.