

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-680WI

SADDLEBAG LIGHT HARNESS

GOLDWING 01-05

11/6/2008

**NOTE: THIS WIRE HARNESS SET IS FOR INSTALLING BBP SADDLEBAG LIGHTS 52-680, 52-735, 52-777 OR 52-787 WITHOUT THE HONDA OEM WIRE HARNESS.**

1. ASSEMBLE O-RING ONTO BULB SOCKET (1B) AS SHOWN IN DIAGRAM 1.
2. INSERT THE BULB OR THE LED PLUG INTO THE BULB SOCKET (1B).
3. INSERT THE BULB SOCKET (1B) INTO THE CORRESPONDING LOCATION ON THE LIGHT.
3. CONNECT EACH PIGTAIL TO THE WIRE HARNESS ACCORDING TO THE DIAGRAM 2. IT IS BEST TO SOLDER THE JOINT; HOWEVER, BUTT CONNECTORS CAN BE USED AS WELL.
4. PLUG THE CONNECTOR (2A) INTO THE BULB SOCKET (1B). TEST FOR FUNCTION.

