

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2008 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 71-326

REAR MASTER CYLINDER COVER  
KAWASAKI VN900

04/16/08

ITEMS NEEDED: 12MM WRENCH      6MM ALLEN WRENCH      THREADLOCKER

**NOTE: WE RECOMMEND USING THREADLOCKER ON ALL HARDWARE INSTALLED.**

1. USING A 12MM WRENCH REMOVE THE HEX FLANGE HEAD BOLT HOLDING THE BRAKE PEDAL TO THE SPLINED SHAFT AND REMOVE THE BRAKE PEDAL. MARK THE PEDAL AND SPLINED SHAFT SO THE BRAKE PEDAL CAN BE INSTALLED BACK TO ITS ORIGINAL POSITION.
2. REMOVE THE TWO HEX FLANGE HEAD BOLTS FROM THE BRACKET HOLDING THE REAR MASTER CYLINDER TO THE FRAME.
3. PLACE THE REAR MASTER CYLINDER COVER OVER THE BRACKET ALIGNING THE HOLES AND INSTALL THE PROVIDED SOCKET HEAD CAP SCREWS. IT IS RECOMMENDED TO START THE REAR SCREW FIRST SO THE COVER CAN BE ROTATED UP ENOUGH THAT YOU CAN SEE WHAT YOU ARE DOING.
4. TIGHTEN DOWN THE TWO SOCKET HEAD CAP SCREWS USING A 6MM ALLEN WRENCH.
5. INSTALL THE BRAKE PEDAL IN REVERSE ORDER OF STEP 1. MAKE SURE THE BRAKE PEDAL IS INSTALLED CORRECTLY SO THAT IT FUNCTIONS PROPERLY. TEST THE REAR BRAKE TO ENSURE IT FUNCTIONS CORRECTLY ONCE THE BRAKE PEDAL IS INSTALLED.