



KHS-020 BREATHER KIT INSTALLATION INSTRUCTIONS

Fits:

'93 & Later 1340 Evo.

Kit contents:

- | | | |
|---------------|---------------------|-------|
| 1. HS42/032 | VENT BOLT ASSEMBLY | 2 ea. |
| 2. Z70/055035 | 5/16" X 3-1/2" HOSE | 2 ea. |

This kit is utilized to connect the stock Harley-Davidson breather outlets to the Mikuni K&N air filter used in the HSR42 and HSR45 carburetor kits. Use the following step by step instructions for easy installation.

1. Use the enclosed vent bolt assemblies and 1/2" flat washers from the original carb kit to attach the air cleaner brackets to the cylinder heads, (don't torque them tight yet).
2. Insert both of the plastic elbows from the original carb kit into each piece of hose from

this kit, then slip the other ends of the hoses onto the two vent bolt nipples.

3. Rotate the plastic elbows so that they point out away from the cylinders. As the air filter is put in place, the elbows will get inserted into the two openings in the rubber backing; these openings have thin membranes in them that should be cut out prior to installing the air filter.

4. Install the air filter now and tighten all of the hardware including the vent bolts, then insert the plastic elbows into the air filter.

