

“THE ULTIMATE “ HIGHWAY MOUNTS FOR HD’S
FRAME MOUNTING ONLY

#HD002, 1 1/8” #HD003, 1 1/4” #HD004, 1 1/2”

1. Remove clamp half from the arm.
2. The arm should be put on with the clamp half facing you as you are sitting on the bike and the screws facing towards the front of the motorcycle. Also note there is a left and right arm. Each is marked inside the arm. The ends of the arms where the pegs pivot is machined at an angle. This is due to the frame tubes being at angles so as to keep the foot pegs horizontal when the arms are mounted. (refer to picture on packaging).
3. Slide the clamp half around the backside of the frame and reattach the arm.
4. Adjust the arm forward/back and up/down until you find the best fit for you.
5. Use the set screw under the peg to adjust the angle of the peg.
6. You can also pivot the peg by loosening the screw at the end of the peg.
7. Check and tighten all hardware.

Good work; now kick up your feet and enjoy!

RIVCO Products, Inc
440 South Pine Street Burlington, WI 53105
262.763.8222 rivcoproducts.com