



IMPORTANT NOTE

ALL PLATES USING THE "SERIES K" KEVLAR MATERIAL SHOULD BE PRE-SOAKED IN OIL FOR FIVE TO TEN MINUTES PRIOR TO INSTALLATION. THIS WILL ALLOW THE PLATES TO SEAT TOGETHER BETTER, MAKING ENGAGEMENT AND ADJUSTMENT EASIER.

IF PLATES ARE TO BE RUN DRY, IT IS STILL RECOMMENDED TO PRE-SOAK IN OIL. BE SURE TO WIPE OFF EXCESS OIL BEFORE INSTALLING.