

11129 G Avenue

(760) 948-4012



Hesperia, CA 92345

Fax (760) 948-4307

30-5028C

Instructions

Long Chrome Covers for: 412-4030C, 412-4037C and 412-4204C only.

Warning: All work should be performed by a qualified mechanic or according to steps outlined in a professional workshop manual that relates to your particular make, model and year motorcycle. Always wear hand and eye protection.

First remove the shocks from your motorcycle per instructions outlined in your owners manual.

1. Remove spring retaining clip from the shock by using an approved spring compressor tool (PS #32-5503).
2. Remove the original top cap and spring.

Figure 1



3. Place the spring guide over the existing body protector with taper as shown in figure 1.
4. Reinstall the spring and the new long chrome cover.
5. Using the spring compressor tool, reinstall the spring retainer clip.
6. Install the shock onto the motorcycle. Be sure to check that it has;
 - a) proper clearances—shock to frame/swingarm
 - b) is not binding or interfering with anything (i.e. swingarm, brake assembly, belt/chain and/or guide, etc.) See figure 2.

Figure 2

