

Instructions for Linbar[®], Multibar[®] Twinbar[®] and Magnumbar[®] Part # 110-1, 1310, 1201, 1710

Fits 2000-present Softail models.

Will work on 2011-up motorcycles with ABS brakes.


**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. On motorcycles with ABS brakes, remove the clip that secures the brake line to the left down tube of the frame.
2. Insert the highway bar from the right side of the motorcycle so the lower left bracket of the highway bar will slide between the frame and the brake line.
3. Install the 5/16" x 1" bolt through the center mount of the highway bar and into the hole in the brace between the two down tubes of the frame and secure with 5/16" washer and nylon locknut.
4. Install the two lower mounts of the highway bar using the 3/8" x 1 1/4" bolts and the 3/8" washers and nylon locknuts.
5. Tighten all nuts and bolts to the manufacturer's specifications and install the clip for the brake line you removed in step 1.
6. Hardware included:
 - 1 Hex bolt 5/16 x 18 x 1
 - 2 Hex bolts 3/8 x 16 x 1 1/4
 - 1 Nylon lock nut 5/16 x 18
 - 2 Nylon lock nut 3/8 x 16
 - 2 Sae flat washers 5/16
 - 4 Sae flat washers 3/8

*Bar width: 32 3/4"



Front Linbar patent D361311
Front Multibar patent D548142

Twinbar patent numbers 6981713 and 7083151