



CHROME SWINGARM COVERS 8256

WITH UN-LIGHTED "PHANTOM" COVERS

FITS: '00-UP SOFTAIL MODELS (EX. '00-UP DEUCE AND '06 STANDARD, NIGHT TRAIN, OR SPRINGER SOFTAIL)

PART #	INCLUDED
408102LC	1 Left Upper Swingarm Cover
408102RC	1 Right Upper Swingarm Cover
408102LLT	1 Left Lower Swingarm Tube Cover – Chrome
408102LUT	1 Left Upper Swingarm Tube Cover – Chrome
408102RLT	1 Right Lower Swingarm Tube Cover – Chrome
408102RUT	1 Right Upper Swingarm Tube Cover – Chrome
608256LC	1 Left Phantom Cover Assembly – Chrome
608256RC	1 Right Phantom Cover Assembly – Chrome
908256	1 Hardware Kit Including: 1 5/16" I.D. Flat Washer – Chrome 3 1/4"-20 Nylock Nuts – Chrome 3 1/4"-20 x 5/8" S.H.C.S. – Chrome 2 Flat Clamps for Upper Swingarm Cover 1 "P" Clamp for Upper Swingarm Cover 2 1/4"-20 x 7/8" H.H.C.S. Hex Bolts – Stainless Steel 2 Mounting Tab Clamps with 1/4" Hole 2 1/4" I.D. Internal Tooth Lock Washers – Zinc 4 10/32 x 1/2" B.S.C.S. – Stainless Steel 4 #10 Wave Washers – Stainless Steel 2 L Brackets
308256	1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KURYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

PROCEDURE

STEP 1 Identify the components used on the right and left sides of the bike. The frame tube covers are cut to length to exactly fit the lengths of tubing on each side of the swingarm. To identify placement of these different tube covers, look for cutouts that will fit around various contours and tabs welded to the swingarm. The rear axle or "Phantom" covers are identified with "L" or "R" on the inner surface.

STEP 2 See PIC.1. Snap the chrome tubing covers into place on each side of the swingarm. Although these fit tightly, you may place a couple small dabs of silicone on the inner surface of each cover for added security.



CUSTOMER SERVICE
877.370.3604 (toll free)

INSTALLATION QUESTIONS
techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY
Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Kuryakyn™ products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA™ All Rights reserved.

PROOF-OF-PURCHASE



STEP 3 Install the upper swingarm covers.

RIGHT SIDE: PIC.2 shows the orientation of the “flat” and “P” style clamps on the cover. The “flat” clamp will be used on the end of the cover nearest the front of the bike, and the “P” clamp will be used nearest the rear. Both clamps are fastened with a 1/4”–20 x 5/8” Socket Head Cap Screw and a Nylock Nut.

LEFT SIDE: This cover will attach in a similar manner to the right side, but instead of the “P” clamp in the rear location, it will attach to the belt guard mounting tab on the swingarm. The stock 5/16” bolt and nut will be used here, but a 5/16” flat washer will be placed over the mounting tab for added strength. (PIC.3 shows an installed upper swingarm cover – right side.)

STEP 4 Install the rear Phantom Covers. Check for proper side orientation. See PIC.4. Install the small tab clamp to the rear of each cover as shown – loosely for now. Use the 1/4”–20 x 7/8” hex head bolts and 1/4” I.D. internal tooth star washers.

STEP 5 See PIC.5. Loosen the rear axle adjuster lock nut – **DO NOT LOOSEN THE ADJUST-ER!** Install the mounting brackets by sliding the brackets between the locknut and the frame as shown. Tighten the locknut against the bracket, firmly pinching the bracket into place.

STEP 6 See PIC.6. “Hook” the rear tab clamp over the end of the Swingarm where indicated. Using the 10–32 B.S.C.S. and #10 Wave Washers, fasten the “Phantom” covers to the mounting brackets. Tighten the 1/4” bolt at the rear of the cover to tighten the tab clamps.

PIC.2



PIC.3



PIC.4



PIC.6



PIC.5

