



## 1. ADAPT YOUR DEVICE

Center the iOadapt and adhere. Wait 8 hours before first use. Use the included iOskin underneath iOadapt to avoid permanency.



## 2. INSTALL

The Kustom Semisphere Mount bolts to the clutch lever clamp. Hardware included. Tools needed: 5mm allen



## 3. ATTACH

Once the iOcore is placed on the Semisphere, your device is ready to be firmly attached.



The Kustom Semisphere Mount attaches to your stock controls. Remove 2 bolts from the controls (left), on the underside of the handlebars, line up the mount, and use included hardware to tighten. Follow factory specs. **Tools needed: 5mm allen wrench**

**WARNING:** When riding or driving, please follow your state laws regarding device use.