



Items Supplied >

- 1 – Chrome Regulator Cover
- 2 – Screws, M6 X 12 mm Buttonhead Stainless Steel

Application(s) >

Kawasaki VN900 2006 - 2010

Instruction Manual >

05-9349

1. Remove the stock bolts and regulator cover from the motorcycle, none of these components will be reused.
2. Place the new chrome cover into the position where the original Kawasaki cover was located and align the holes in the part with those on the regulator. Insert the supplied M6 x 12mm screws and prior to tightening the screws fully align the cover with the radiator or radiator cover if purchased, above it.
3. Once the cover has been aligned tighten the screws to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*



Items Supplied >

- 1 – Chrome Regulator Cover
- 2 – Screws, M6 X 12 mm Buttonhead Stainless Steel

Application(s) >

Kawasaki VN900 2006 - 2010

Instruction Manual >

05-9349

1. Remove the stock bolts and regulator cover from the motorcycle, none of these components will be reused.
2. Place the new chrome cover into the position where the original Kawasaki cover was located and align the holes in the part with those on the regulator. Insert the supplied M6 x 12mm screws and prior to tightening the screws fully align the cover with the radiator or radiator cover if purchased, above it.
3. Once the cover has been aligned tighten the screws to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*