

Items Supplied >

- 1 – Front Muffler
- 1 – Rear Muffler
- 1 – Front Head Pipe
- 1 – Rear Head Pipe
- 1 – Front Heat Shield
- 1 – Rear Top Heat Shield
- 1 – Rear Left Heat Shield
- 2 – #268-60 T-Bolt Clamps
- 4 – 8mm Hex Nuts
- 4 – 5/16" Lock Washers;
- 4 – 5/16" Flat Washers

Application >

- KAWASAKI VULCAN 1500G NOMAD 98-04
- KAWASAKI VULCAN 1600D NOMAD 05-08

Instruction Manual >

4167/4167SC/4167SD

Page 1 of 1

PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.

1. Remove both saddlebags by removing the two (2) bolts on the inside of each bag and pulling up on the bag itself.
2. Remove the stock exhaust system.
3. Install the longest heat shield on the front cylinder head pipe but **DO NOT TIGHTEN CLAMPS**.
4. Install the front head pipe using stock flanges and nuts.
5. Install the rear head pipe using stock flanges and nuts (this will go under the swing arm and exit on the left side).
6. Install right side muffler body using your stock bolts and supplied t-bolt clamp, 8mm nuts, washers, and lock washers. As a guideline for proper muffler position, make sure the muffler is parallel with the bottom bag rail support bracket.
7. Install left side muffler body using your stock bolts and supplied t-bolt clamp, 8mm nuts, washers, and lock washers. Again, make sure the muffler is parallel with the bottom bag rail support bracket.
8. Install the 90° curved heat shield on the left side in front of the muffler body. Install the remaining heat shield on the right side rear head pipe just below the flange. When installed, this heat shield will meet the heat shield on the front head pipe.
9. Tighten all bolts and clamps. Check heat shields for proper positioning and tighten clamps.

IMPORTANT: For carbureted models it is recommended that you re-jet your bike with a Cobra Jet Kit, part # 92-4168.

For fuel-injected models It is recommended that you install a Cobra Fi2000 Digital Fuel Processor with your Cobra exhaust system (part# 92-0941 or 92-1963). Cobra is not responsible for the performance of any other fuel management system used with Cobra exhaust systems.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*