

Items Supplied >

- 1 - Tank Mount Cover
- 1 - 6mm x 35mm Flathead Allen Bolt

Application(s) >

- VALKYRIE 97-02
- VALKYRIE TOURER 98-00

Instruction Manual >

05-0062

1. Remove the small bolt at the front of your fuel tank that secures it to the frame.
2. Raise the fuel tank slightly and insert the large triangular plate in between the frame and your fuel tank mount tab.
3. Place the small tab cover over the fuel tank tab. Align the holes in the tab cover, fuel tank mount tab, and the triangular plate.
4. Secure with the Allen bolt provided.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A

10/00

Anything's Possible.

Items Supplied >

- 1 - Tank Mount Cover
- 1 - 6mm x 35mm Flathead Allen Bolt

Application(s) >

- VALKYRIE 97-02
- VALKYRIE TOURER 98-00

Instruction Manual >

05-0062

1. Remove the small bolt at the front of your fuel tank that secures it to the frame.
2. Raise the fuel tank slightly and insert the large triangular plate in between the frame and your fuel tank mount tab.
3. Place the small tab cover over the fuel tank tab. Align the holes in the tab cover, fuel tank mount tab, and the triangular plate.
4. Secure with the Allen bolt provided.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A

10/00

Anything's Possible.