

Lindby Custom, Inc.

PART # 906-1

Instructions: front Linbar fits Honda VTX 1800 Retro 2001-up.

Do not fit the VTX 1800 Classic.

Patent Number D361311

Remove the 3 bolts that holds on the radiator to the frame and loosen the upper radiator hose clamp and rotate a 180 degrees. Tighten again (make sure the engine is cold and that there is no pressure in the system)

Remove the 2 lower bolts on left and right floorboards.

Install the top mount of the highway bar between the frame and the radiator and install the 6mm bolt. Do not tighten yet. Install the 2 lower bolts for the radiator.

Install the 2 lower bolts through the highway bar and into the frame on the floorboards and tighten all bolts to the manufactures specifications.

Warning:

The combined engine guard and highway peg are for cosmetic use only and will not provide body or vehicle protection in the event of a fall of any speed. They are not made nor intended to provide protection from bodily injury in a collision with an automobile or any other object.