

GP-GRX2 DUAL GARAGE DOOR KIT

Installation Instructions:

- 1: Remove the two Torx bolts from stock clutch lever bracket (Clampshell side)
- 2: Replace stock Clutch “Clampshell” bracket with “Grip Switch” bracket using stock Torx bolts.
NOTE: Neither The stock Clampshell bracket, or “Grip Switch housing” are intended to achieve anti-rotation on the handlebar. They are designed to integrate (lock in) with stock Harley controls which provide that function. Tightening our housing without having it “nested in” or properly aligned can cause damage to the Nylon when tightening, and is not covered by Warranty. (60 days) Use only a screwdriver style Hex/Torx head wrench and do not tighten over 6-7 lbs. Always use thread locker.
- 3: **GARAGE DOOR OPENER:** Temporarily Connect Grip Switch wires to sender wires using the mid-wire blade disconnects:
NOTE: Before you make the 4 Male to Female connections, Please have wire routing finalized before **fully** inserting mid-wire disconnects. Blade connectors are difficult to take apart once fully inserted. Just a tip, other than that, don't worry, there is no way to hook these up wrong.
4. Press both top and bottom of the “Grip Switch” rocker and determine that both will cause the sender lights to flash.
5. Press top Rocker button to Program first garage door using the factory included instructions / codes for your particular Garage door. Press bottom of Rocker to program the second Garage door using the factory instructions for that particular Garage door. Do not use the sender to do any of the programming, use the “GripSwitch” rocker only. Do the programming before you have the sending unit installed in its final location, or at least where you can still see the sending unit and it's lights.
- 6: Place sender unit preferably in front portion of motorcycle. (Headlight nacelle, Fairing, Etc.)
- 7 Use provided double- sided tape for mounting of sender unit. **Note:** Battery is already installed in sender.
- 8: Use included free package of Sheerloc brand wire fasteners for maximum concealment of wiring.

Troubleshooting

Any issues are usually low battery. It is rare for the system to lose its programming. Hold on to the programming instructions, however, they may come in handy someday!

Customer service can be reached at: 909 557 3860 and must be contacted before any returns can be authorized. Any returns that are not a result of component malfunction must be submitted to the manufacturer within 15 days of receipt or they may be subject to a 15% restocking fee. Returns must include all “clamshell” packaging and be in un-tampered :as new condition”.



GP-GRX2 (Dual Garage Door Kit)