

WIRING KIT FOR 1938 - 1946

All Models ex. Servicar, Part No. 4735-38A

Complete Set of Wiring

- | | | |
|----------|---|--|
| 1613-30A | Circuit breaker to coil wire | black 25" |
| 1741-38 | Switch to generator and relay cable | red, black, green 40" |
| 4701-38 | Switch to coil, tail lamp and battery positive junction terminal cable | red, black, green 28" |
| | 4703-38 Pressure switch to signal lamp wire attached to cable | black 42" |
| 4702-38 | Headlamp to handlebar toggle switch cable | red w/black, red w/ yellow
black w/ red 26" |
| 4703-36 | Switch to horn and toggle switch cable | red, green 25" |
| 4704-39B | Stop and tail lamp wire | black, red 73" |
| 4706-36 | Battery negative ground wire
Correct length for 1938-40 models. For 1941 and later shorten to 3 1/2" and attach enc. terminals | black 9" |
| 4706-37 | Battery positive wire | red 9" |
| 4706-39 | Generator to relay wire
Wire is correct length for side valve models. For OHVs shorten to 5 1/2" and attach enc. terminal | red 9" |
| 4708-38A | Switch to signal lamp wire | black 5" |
| 4710-36 | Horn switch wire | black 29" |
| 4712-36 | Panel lamp contact wires | 2 - black 5" w/ 1 terminal |
| 4733-39 | Coil to stop lamp switch wire | green 19" |
| 13409-34 | Fender light wire | black 36" |

