

## USER GUIDE & INSTALLATION INSTRUCTIONS

DESCRIPTION: Crus'n Deluxe Sissy Bar Bags PART NUMBER: 3515-0171, 3515-0172, 3515-0173

### CONTENTS / PARTS INCLUDED:

3515-0171



- 1 Sissybar Bag
- 1 Top Roll Bag
- 1 Back Pack Strap
- 2 Mounting Rod
- 1 Jumbo Pad Extension Mount
- 1 Rain Cover
- 2 Side Mounted Hold-Down Straps
- 2 Roll Bag Securing Straps
- 1 Yoke Security Strap
- 1 Shoulder Strap
- 1 Installation Instruction

3515-0172



- 1 Sissybar Bag
- 1 Shoulder Strap
- 2 Mounting Rod
- 1 Jumbo Pad Extension Mount
- 1 Rain Cover
- 2 Side Mounted Hold-Down Straps
- 1 Yoke Security Strap
- 1 Installation Instruction

3515-0173



- 1 Sissybar Bag
- 1 Shoulder Strap
- 2 Mounting Rod
- 1 Jumbo Pad Extension Mount
- 1 Rain Cover
- 2 Side Mounted Hold-Down Straps
- 1 Yoke Security Strap
- 1 Installation Instruction

### IMPORTANT:

These installation instructions cover the Crus'n Deluxe family of Sissybar bags. Mounting the three (3) styles are the same. Features differ due to their size.

Please read these instructions completely before starting installation. All **“NOTE,”** **“CAUTION”** and **“WARNING”** notations are serious safety issues and should be read carefully. Possible injury to riders or damage to the motorcycle and/or accessory may result if improperly installed.

## NOTICE TO DEALERS:

These instructions contain important information for future reference and should be given to the customer.

### WARNING:

You are responsible for the correct installation and safe use of this Sissybar bag. Seek qualified instruction if you are uncertain about its capabilities and limitations or if you need help with installation. Use of the bag in a manner other than its intended purpose or contradictory to the warnings and instruction provided could cause loss of control of your motorcycle, possibly resulting in personal injury or death.

- Do not use this bag if any part of the mounting system has deteriorated, loosened or is beginning to fail. If you have any doubts as to the security of bag's installation, stop using it.
- After every stop check the bag to be certain that it did not shift while riding and verify that the straps will not contact or interfere with any part of the drivetrain, suspension, brakes or wheels.
- Do not exceed 10 pounds of loaded weight into the bag for part numbers 3515-0172 & 3515-0173 or 15 pounds of loaded weight for part number 3515-0171, or the load limits of the motorcycle as specified in the owner's manual supplied with the bike or from the bike manufacturer.
- When the bag is removed, all loose straps must be removed from the motorcycle, or secured, so that they do not contact or interfere with any part of the drivetrain, suspension, brakes or wheels before operating the motorcycle.
- Always remove or stow all shoulder and backpack straps before attaching bag to motorcycle.
- **DO NOT ATTEMPT TO USE THESE ITEMS IF....you do not understand these instructions...you do not understand any part of the mounting system...you have any doubts as to the security of the mounting system.**

If you have any doubts or questions, **SEEK PROFESSIONAL HELP** at your qualified motorcycle dealer or call **SADDLEMEN** at 310-638-1222.

Motorcycling is an inherently dangerous activity. Installation of any accessory, including this Sissybar bag can add to the danger if it is not installed safely. You must install this product in a manner in which it will not contact any part of the drive train, suspension or steering, or interfere with any operation of the motorcycle. If you do not know how to do this, or have any doubts as to your ability, please see a qualified motorcycle mechanic.

### WARNING:

To avoid injury, install while engine is cold.

### CAUTION:

- Park the motorcycle on a hard, level surface and turn off the ignition before installation or securing any part of this product or items that might be attached to this product.
- **DO NOT** connect any mounting straps or any additional securing straps to flexible or moving parts (rubber mounted turn signals, swing arm, shocks, wheels etc.)
- You must tuck away, tie, or cut/shorten all loose mounting straps **BEFORE** you ride the motorcycle.

## OVERVIEW:


- The main cargo compartment flap opens fully with solid tethered sides for easy loading
- Internal mesh storage compartments secures cargo while keeping it visible
- Adjustable mounting sleeve adapts to the shape and width of your bike's Sissybar
- Fully adjustable, high strength nylon webbing hold-down straps are supplied – you can mount the bag easily even if you don't have a rear rack.
- Multiple mounting rings around the bag overcome unique mounting challenges
- Can be used with Saddlemen's Versa Mount System (#3550-0117) to mount directly to a seat; does not require a Sissybar or backrest
- Rigid luggage shell maintains its shape regardless of cargo load, yet is lightweight to reduce the impact on your motorcycle.
- Marine-spec materials and stitching holds up the elements to give you decades of sound use
- Strong, nylon meshing zipper teeth with chrome sliders equipped with large pulls for easy use with a gloved hand
- High visibility yellow, reflective rain cover with locking cinch cord included

## INSTALLATION:



### MAIN BAG (3515-0171, 3515-0172, 3515-0173)

1. Refer to diagram below. Use the included mounting rods to adjust the width of the Crus'n Deluxe Sissybar bag mounting strap to fit snugly around your bike's sissy bar pad. The mounting rods can be inserted to make the strap narrow or wide. You can also insert the rods at an angle if your sissy bar pad is not rectangular. If you have a very large Sissybar pad, a Jumbo Pad Extension Mount has been provided. This mounts onto the mounting rods and is used in lieu of the attached mounting strap.
2. Make sure the mounting rods are fully inserted, through the upper mounting loops and solidly into the lower mounting loops. Once in place, tightly close the hook and loop retention flaps that are above each set of upper mounting loops.



3. The Sissybar yoke provides vertical support for Sissybar' s that do not have a rack. To use this option simply slide the yoke inside the mounting strap and mate the hook and loop at the desired height. (\*note: bag should not rest on any moving or painted surfaces).
4. Mount the yoke security strap by attaching the clip to the yoke D-ring located at the end of the yoke and weaving it as shown through the yoke ladder lock. Snug but do not over tighten.
5. Each bag also has two side mounted hold down straps, one located on either side of the bag. The straps connect to the D-rings which are also used for the back pack straps. These are designed to hold the bag tight to the rack or seat. The straps must clip into the corresponding D-rings on each side of the bag, and wrap around a secure, solid part of the motorcycle like a saddlebag support, frame rail, etc. Once all of the straps are connected, the bag should not move around while the motorcycle is operating.

#### TOP ROLL BAG (3515-0171 only)

1. Place top roll bag on top of main bag.
2. Run nylon straps under flap on top of bag next to handle. Once strap is in place, tightly close the hook and loop flap.
3. Fasten clip to D-rings on front of bag.
4. Thread other end of strap through ladder lock as shown below and tighten strap.

#### INSTALLING STRAPS TO LADDER LOCKS (Yoke Security Strap & Roll Bag)



#### ADJUSTABLE INTERNAL SHELF (3515-0171 only)

Internal shelf adjusts by separating the movable hook and loop flaps from the bag's body and re-placing them so that shelf is level and where you need it.

#### BACKPACK STRAPS (3515-0171 only)

Clip one backpack strap end to a D-ring located on the lower rear corner of your bag. Feed the strap thru the D-ring located at the top center of the rear of the bag, and then clip the other end of the strap to the other lower D-ring.

## SHOULDER STRAP

Sissybar bags 3515-0172 & 3515-0173 and the top roll bag for 3515-0171 are designed with an optional shoulder strap (included). To use attach clip one end to the D-ring mounted above the side pocket. Repeat process on the opposite side. Adjust length as needed.

## RAIN COVER

Carefully place the rain cover over the bag so the cinching cord is around the base of the luggage. Once the cover is in place, cinch it tight at the base by pulling on the cord and locking it in place with the barrel-shaped cord lock.

### IMPORTANT:

- Take extra care when installing the rain cover so it will not come loose or interfere with the motorcycle's controls, suspension, wheels or other components. Do not operate your motorcycle unless you are certain the rain cover is properly secured.
- Failure to install any of these accessories properly may allow portions of a bag or its mounting straps to come into contact with the motorcycle's moving parts or controls. It is vital that you verify that neither the accessory, nor any of its parts touch, or interfere with, other motorcycle components while the steering and suspension moves through its entire range of motion.
- Make sure that accessory or its mounting straps or hardware cannot come into contact with the exhaust or any other component of the motorcycle, as other vehicle components may be damaged by contact with this accessory.
- It is your responsibility to make sure the installation of this accessory does not create an unsafe or illegal condition. Check to be sure that all lights and safety reflectors are visible once your accessory bag is in place. If the bag blocks any side reflectors, place reflectors on the exterior sides of the bags (reflectors with self-adhesive backing are available from motorcycle or automobile supply stores).
- After 50 miles (80 kilometers) of riding, recheck the accessory bags and the mounting straps to make sure that they are still tight and secure. Inspect the bags and their mounting hardware more often if you are riding your motorcycle in wet or rough conditions. Inspect the accessory and related hardware before and during each ride. A loose accessory and/or mounting hardware can interfere with the vehicle's operation and cause an unsafe riding condition.

## CARE AND CLEANING

Your Saddlemen bag requires almost no maintenance other than periodic cleaning with mild soap and water

### NOTE:

## SADDLEMEN'S ONE-YEAR WARRANTY

We guarantee our products for a period of one year after retail purchase, against defects in materials and workmanship. Damage caused by improper use or incorrect mounting is not warranted. Our warranty has other provisions and conditions; please contact Saddlemen for full details. If your Saddlemen product is not performing to your expectations, please call us directly and our customer service staff will be happy to help. You can count on Saddlemen's quality, innovation, service and style. If your Saddlemen product is not performing to your expectations, please call us directly and our customer