



Custom Dynamics® Plug & Play Passing Lamp Adapters Installation Instructions

We thank you for purchasing the Custom Dynamics® Passing Lamp Adapters! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CDTB-PLA

Package Contents:

- Passing Lamp Adapters (pair)
- Insulated Female Spade Connectors (4)
- Instructions

Fitment: 2004 & Earlier HD models- stock 4 1/2" passing lamps with/without spade connectors upgrading to 2005 & newer style passing lamps and/or LEDs.



ATTENTION



Please read all information below before installation

Important: Park motorcycle on a hard level surface, turn off ignition.

Caution: Disconnect the Negative [-] battery cable from the battery before starting the installation procedure. Failure to do this may result in electrical shock, potential damage to product and/or damage to the bike.

Note: Secure all wiring away from sensitive areas, moving parts, pinch points and extreme heat. Damage to units caused by pinched, broken, frayed, melted or improperly crimped wires will not be covered under warranty.

Installation

For motorcycles with female spade connectors installed on wires to the lamp (commonly on 1999-2004 models):

1. Remove the stock headlamps.
2. Connect the red wire from the new adapter to the gray/black striped wire in the housing.
3. Connect the black wire on the adapter to the black wire in the housing.

For motorcycles without female spade connectors installed (commonly on 1998 and earlier models):

1. Cut the connector off of each wire in the lamp housing.
2. Strip 1/4" of insulation from the end of the lamp wires.
3. Using the provided Female spade connectors, crimp the connectors onto each lamp wire with a suitable crimping tool.
4. Connect the red wire from the new adapter to the gray/black striped [+] wire in the housing.
5. Connect the black wire on the adapter to the black [-] wire in the housing.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM